



Sporicidin[®] Enzyme Cleaner Concentrate

Highly concentrated solution for professional Cleaning & Restoration

Description

A combination of protease (to remove protein), amylase (to remove starch), lipase (to remove fat), and surfactants (to remove oils and chemicals).

Softens organic contamination for easier removal. Makes blood and other dried organic matter easier to remediate. Works well with smoke from fires, dirt and oily residue from floods, sewage residue, pet stains and pet odors, as well as some chemical residues. Makes scrubbing and removal of contamination easier.

Rehydrates water soluble chemical residues.
Floats away oily chemical residues

Recommended for use on floors, walls, ceilings, painted surfaces, metal, tile, concrete, cinder block, brick, carpet, fabric, upholstery, plastic, glass, vinyl, latex, wood studs, joists, beams, sub floors, and other materials subject to moisture.

Ideal for use with a foamer for flood damage restoration.

Meets the stringent requirements of EPA's Safer Choice environmentally friendly cleaning products program.

Technical Data

ATTRIBUTES	Value	Notes
pH	7.5	Mild Alkaline



Part Number	Description	Packaging
ENZ-3212	Sporicidin Enzyme Cleaner Concentrate, 32oz (0.95L)	12 each/case
ENZ-MOLD55GAL	Sporicidin Enzyme Cleaner Concentrate, 55-gallon (208.2 L) drum	4 drums/pallet

Notes:

- 1) The information presented here is applicable to the part numbers shown above as well as to any product containing the same materials and produced under the same conditions, regardless of product size or packaging configuration. Please contact a Contec sales representative for more details.
- 2) Data shown are typical values and should not be used as product specifications.
- 3) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- 4) Current and/or comparison data may be available. Please contact a Contec sales representative for details.

Revision date: 01/10/18



Copyright © 2018 Contec, Inc. All rights reserved.

North America
P.O. Box 530
Spartanburg, SC 29304 USA
Phone: +1-864-503-8333
www.contecinc.com

Europe
ZI du Prat – RP 3707
56037 VANNES Cedex
FRANCE
+33 297 437 698

China
No.17 Longyun Road
Suzhou 215024
CHINA
+ 86-512-6274 4050

Directions for Use:

Before applying, always test for colorfastness or surface impact in inconspicuous area prior to usage. For general cleaning add 2 ounces of Enzyme Cleaner Concentrate to one gallon of cold or warm water and mix thoroughly. Apply solution to surface or material to be cleaned. Allow at least one minute of wet contact time before wiping or scrubbing to remove debris. Rinse with water and wipe or extract to remove all residue when cleaning has been completed.

Removal of Blood, Bodily Fluids and Other Biological Contamination from Surfaces and Materials:

Follow OSHA Bloodborne Pathogen Standard, all applicable regulations and industry standards. Contaminated surfaces should be pre-cleaned with diluted Enzyme Cleaner Concentrate solution to loosen and remove gross filth using directions above. Once surface contamination has been removed, non-porous surfaces should be disinfected using an EPA-registered Tuberculocidal disinfectant, such as Sporidicin® Disinfectant Solution, Sporidicin® Disinfectant Towelettes, or Contec® Citric Acid Disinfectant to deactivate pathogens and biological contamination. Porous materials may be sanitized with an EPA-registered sanitizing agent labeled for such purposes.

For heavy organic contamination, such as dried blood, mix 8 ounces into a gallon of water. Clean and reapply as needed.

Carpet and Fabrics: Apply diluted solution to carpets using a coarse-tip pressure sprayer (coverage rate is typically 400 square feet/gallon). Gently work into carpet fibers, then extract using a carpet cleaning machine. Dry carpets thoroughly with fans or air-movers. Stubborn or heavy traffic lanes may require repeated applications.

Fabric and Spot Cleaning: Apply diluted solution to soiled area and allow to dwell up to ten minutes. Gently blot and absorb excess with soft, clean cloth until satisfied with results and treated area is dry to touch. Rinse and extract to remove any enzyme or surfactant residue.

Precautions:

Keep Out of Reach of Children

WARNING: Causes skin and eye irritation. **PRECAUTION:** Wash hands thoroughly after handling. Wear protective gloves, protective clothing, and eye protection. **First Aid: IF IN EYES:** Immediately flush with water for at least 20 minutes. Remove contact lenses if present and easy to do. Continue rinsing. If irritation persists, seek medical attention. **IF ON SKIN:** Wash with plenty of soap and water. If skin irritation or rash occurs: Get medical advice/attention. Wash contaminated clothing before reuse.

Storage: Store between 10 °C - 50°C or 50°F - 122°F.

Disposal: Discard used solution daily or more frequently if solution becomes visibly soiled. Flush used solution down the regular drain. Dispose container in regular trash according to local regulations.

Notes:

- 1) The information presented here is applicable to the part numbers shown above as well as to any product containing the same materials and produced under the same conditions, regardless of product size or packaging configuration. Please contact a Contec sales representative for more details.
- 2) Data shown are typical values and should not be used as product specifications.
- 3) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- 4) Current and/or comparison data may be available. Please contact a Contec sales representative for details.

Revision date: 01/10/18



Copyright © 2018 Contec, Inc. All rights reserved.

North America
P.O. Box 530
Spartanburg, SC 29304 USA
Phone: +1-864-503-8333
www.contecinc.com

Europe
ZI du Prat – RP 3707
56037 VANNES Cedex
FRANCE
+33 297 437 698

China
No.17 Longyun Road
Suzhou 215024
CHINA
+ 86-512-6274 4050